


Installation manual YORK HK417/G28/MR308 Magazine Extension +5

Step 1 - Remove stock baseplate



Step 2 - Install YORK HK417/G28/MR308 Magazine Extension +5



OR

